


Adjusting your "high wind" Waterbird parasail



Your Waterbird® high wind parasail is provided with adjustable zip pressure vents.

These vents allow your parasail to be used in a wider range of wind speeds.

To use the vents simply open both vents fully when flying in winds stronger than are normal for the size of canopy.

To use the parasail in your normal wind conditions ensure both vents are fully closed.

NEVER OPEN OR CLOSE ONLY ONE VENT. THIS COULD LEAD TO THE PARASAIL FLYING UNPREDICTABLY.

Email: info@waterbird.co.uk

Tel: + 44 (0) 1474 853675 / Fax: + 44 (0) 1474 854474